H05 hinge 12-13mm & 17-19mm & 19-21mm



Includes fixings for wall and fascia fix		
Panel thickness	ANODISED	РРС
12-13mm	H05213A	H05213P
17-19mm	H05219A	H05219P
19-21mm	H05220A	H05220P





The hinge fall position can be adjusted by removing and rotating the nylon hinge risers. Note: Approx. 3.5mm rise and fall travel.

- 1. Dismantle the hinge by removing the mushroom head screw.
- 2. Adjust the nylon Cam to give the correct rise/fall for the hinge. Supplied open as default.
- 3. Predrill the door and fascia's using the Below drawing as a reference.
- 4. Fit the top half of the hinge (pin pointing down) to the door.
- 5. Fit the bottom half (no pin) to the fascia.
- 6. Lift the door into position and drop over the lower hinge half.
- 7. Refit the mushroom screw and check operation.

